

Tools Needed: Ratchet, 17mm, 13mm, 10mm, 5/8", E12, 5mm allen, 6mm allen, and 3/8" allen sockets, T20 and T30 torx drivers, Phillips screw driver, plastic wedge

1. Disconnect battery.
2. Remove seats.
3. Remove center console.
4. Remove parking brake handle
5. Remove door sill trim panels.
6. Remove rear seats (if present).
7. Remove Bose speaker (if present).
8. Remove B pillar trim.
9. Remove rear side panel linings.

Note:

If installing the 901 in a GT3 or GT3 RS the rear carpet lining must be removed in order to gain access to the rear seat belt mounting holes. Remove the factory plugs and reinstall the rear carpet lining. Carefully trim carpet to expose the rear seat belt mounting holes.

10. Remove rear seat belts if they are to be eliminated.
11. Pull back carpet covering wiring loom covers.
12. Trim wiring loom covers and replace carpet.
13. Install rear side panel linings.
14. Install B pillar trim.
15. Install Bose speaker.
16. Install 901 Rollbar. Torque all fastening hardware to 50N\*m/37lbs\*ft.

Note:

For ease of installation it is permissible to pull the front half of the 901 together with a suitable strap, e.g., a ratcheting tie down. Before using the strap, be sure to adequately protect the painted surface where the strap will come in contact with the rollbar.

17. Install door sill trim panels.
18. Install parking brake handle.
19. Install center console.
20. Install seats.
21. Connect battery.